


# Audio System

## System Description (cont'd)

### Audio Unit Connector A (17P)



Terminal side of male terminals

#### With navigation

Cavity	Wire	Connects to
A1	RED	Dash lights brightness controller (ILL+)
A2	PUR	Stereo amplifier (RL SIG—)
A3	GRN	Stereo amplifier (FL SIG—)
A4	GRN	Multiplex integrated control unit (MICU) (SCTY RADIO)
A5	—	Not used
A6	LT BLU	Multiplex integrated control unit (MICU) (K-LINE)
A7	YEL	Stereo amplifier (FR SIG—)
A8	PNK	Stereo amplifier (RR SIG—)
A9	BLK	Ground (G504)
A10	GRY	Lights-on signal
A11	LT GRN	Stereo amplifier (RL SIG+)
A12	RED	Stereo amplifier (FL SIG+)
A13	BLU	PCM (VSP)
A14	WHT	Multiplex integrated control unit (MICU), Stereo amplifier (ACC RADIO) (Fuse No. 34 (7.5 A) in the under-dash fuse/relay box)
A15	BRN	Stereo amplifier (FR SIG+)
A16	BLU	Stereo amplifier (RR SIG+)
A17	LT GRN	Constant power (Fuse No. 23 (10 A) in the under-hood fuse/relay box)

#### Without navigation

Cavity	Wire	Connects to
A1	RED	Dash lights brightness controller (ILL+)
A2	BRN	Left rear speaker (RR L—)
A3	GRN	Driver's door speaker, Left tweeter (FR L—)
A4	GRN	Multiplex integrated control unit (MICU) (SCTY RADIO-G504)
A5	—	Not used
A6	LT BLU	Multiplex integrated control unit (MICU) (K-LINE)
A7	YEL	Front passenger's door speaker, Right tweeter (FR R—)
A8	ORN	Right rear speaker (RR R—)
A9	BLK	Ground (G504)
A10	GRY	Lights-on signal
A11	GRY	Left rear speaker (RR L+)
A12	LT GRN	Driver's door speaker, Left tweeter (FR L+)
A13	BLU	PCM (VSP)
A14	WHT	Multiplex integrated control unit (MICU) (ACC RADIO)
A15	WHT	Front passenger's door speaker, Right tweeter (FR R+)
A16	BLU	Right rear speaker (RR R+)
A17	ORN	Constant power