




Audio Unit Connector B (22P) (with navigation)




Terminal side of male terminals

With navigation

Cavity	Wire	Connects to
B1	BLK	Auxiliary jack assembly (AUX SGND)
B2	GRY	Auxiliary jack assembly (AUX SHIELD GND)
B3	PNK	Auxiliary jack assembly (AUX GND)
B4	—	Not used
B5	—	Not used
B6	BRN	Audio remote switch (AUDIO REMOTE GND)
B7	PNK	Audio remote switch (AUDIO REMOTE SW)
B8	—	Not used
B9	—	Not used
B10	—	Not used
B11	WHT	Auxiliary jack assembly (AUX L)
B12	RED	Auxiliary jack assembly (AUX R)
B13	LT BLU	Auxiliary jack assembly (AUX DET)
B14	—	Not used
B15	BLK	Ground (G502)
B16	—	Not used
B17	—	Not used
B18	—	Not used
B19	—	Not used
B20	RED	Stereo amplifier (AMP ON)
B21	—	Not used
B22	—	Not used

Audio Unit Connector B (20P) (without navigation)



Terminal side of male terminals

Without navigation

Cavity	Wire	Connects to
		Not used
		Not used
	RED ^{*1}	Auxiliary jack assembly (AUX SGND)
	BLK ^{*2}	Auxiliary jack assembly (AUX SHIELD GND)
	GRY ^{*2}	Auxiliary jack assembly (AUX GND)
B5	GRN ^{*1}	Auxiliary jack assembly (AUX SHIELD GND)
B6	PNK ^{*2}	Auxiliary jack assembly (AUX GND)
B6	BRN ^{*2}	Audio remote switch (AUDIO REMOTE GND)
B7	PNK ^{*2}	Audio remote switch (AUDIO REMOTE SW)
B8	—	Not used
B9	—	Not used
B10	—	Not used
B11	—	Not used
B12	—	Not used
B13	WHT	Auxiliary jack assembly (AUX L)
B14	BLK ^{*1}	Auxiliary jack assembly (AUX R)
B14	RED ^{*2}	Auxiliary jack assembly (AUX DET)
B15	LT BLU	Auxiliary jack assembly (AUX DET)
B16	—	Not used
B17	—	Not used
B18	—	Not used
B19	—	Not used
B20	—	Not used

* 1: LX model

* 2: Except LX model

(cont'd)